

# Popcorn

Follow these directions and let the fun begin.

- Plug machine into 115 volt grounded outlet with a minimum of 10 amps available.
- Turn on kettle switch, lights and warmer, and kettle heat.
- For first batch only, let kettle heat about 4 minutes.
- Turn on kettle motor.
- Add oil, salt, and popcorn all at once.
- When corn has popped, rotate the handle to empty popcorn from kettle; return kettle to upright position.
- Repeat the cycle-subsequent batches are always more flavorful than the initial batch.
- Turn off the kettle heat switch near the completion of the final batch. Eliminate smoke and odor by turning off kettle heat when the popcorn breaks over the lid.
- Turn off kettle motor.
- After kettle has cooled, wipe exterior of kettle with heavy cloth to prevent burn or stain of oil drippings.

Turn off all switches.

Tip: When popping, leave the doors open to allow the steam to escape. After popping, keep the doors closed to maintain the popcorn warmer's heat.

## **Cleaning Tips:**

- Allow kettle to cool. Unplug kettle and remove from machine.
  - Wipe clean with a terry-cloth towel: the kettle, kettle lids, crossbar, and exterior. DO NOT IMMERSE KETTLE IN WATER!
  - Remove popped corn.
  - Remove the "old maid" pan, empty unpopped kernals, and wipe clean.
- 6.Clean the inside of the machine with a terry-cloth towel. DO NOT USE ANY CLEANER!

\*\*Understand your rental contract and know your responsibility for the equipment you have rented\*\*

**P: 414.427.9951**

